
4K Hidden Video: Zone Shield and Xtreme Life DVRs



3 Steps to Set Your Optional Settings with the MenuSettings App

Step 1: Insert the SD card into an SD card reader. Insert the SD card reader into your computer and open the file named MenuSetting (PC) and MenuSetting.app (Mac). A window with all the optional settings for your 4K SG Home camera will appear. (See other side for detailed optional settings.)

Do NOT copy the app to your computer.

Step 2: Choose your settings including resolution, PIR detection and sensitivity, and scheduled recordings. Click OK to save these settings to the SD card.

Do NOT save the settings file to your computer.

Step 3: Eject the SD card from your reader and insert it into your 4K SG Home camera. The settings file will automatically update the settings to the onboard processor in the 4K SG Home camera.

